



PROCEDURE LIST OF SPACE-TITE SYSTEM ASSEMBLY

Required Tools:

- Tape Measure
- Metric allen Wrench Set
- 2" Pipe Cutter
- Rubber Mallet
- Box Cutter
- Space Drawing

INSTRUCTIONS

1. Measure room dimensions to make sure they match drawing.
1. Count all boxes against packing list.
2. Measure Stainless overhead guide bar and make any necessary changes.
3. Open and move aside all boxes prior to assembly.
4. Remove black post caps from all posts.
5. Assemble all shelf units and put into place as directed by drawing (remember to put foot plates on stationary units during assembly).
6. Place guide blocks and locking collars in place on overhead guide bar.
7. Starting at one end, place guide blocks into posts and work your way down the assembly until complete.
9. Tighten down all locking collars.
10. Align the height of the stationary units until the mobile units move freely.